#### **Power Pack**





Project Name: Location: TR 100 Specifications Item No. 63101 Voltage 120/230/277 VAC, 50/60 Hz Output 24 VDC +/- 5% 250 mA (class 2) Load 20 A @ 120/230/277 VAC 50/60 Hz - ballast and incandescent load 1 hp @ 120-240 VAC, 50/60 Hz 20 A @120 VAC, 50/60 Hz - receptacle load IP20 rated, -4°F to +130°F, -20°C to +55°C Environment Dimensions 2.4 x 3.2 x 1.5 in (LxWxD) 60 x 81 x 39 mm Threaded Nipple .83 x .83 in Dimensions 21 x 21 mm Warranty 5 years C-UL-US Listed Certifications RoHS Compliant, UL 2043 Plenum Rated

The TR 100 is a full featured power pack that provides power to STEINEL low voltage occupancy sensors and other control devides. They are Class 2 output power supplies, suitable for parallel interconnection.

The power packs switch the load(s) ON and OFF in response to signals from the control devices. Each power pack contains a Mode Switch to select either manual ON or automatic ON operation. In manual ON mode, occupants operate a low voltage momentary switch to turn lights ON.

All wires have UL Style 1659, 250°C, 600V insulation:

- 18 AWG: Black for Line and White for Neutral
- 12 AWG: two Red wires for normally open dry contact from the 20A relay
- 22 AWG: 4 low voltage conductors: Red (+24VDC), Black (-24VDC), Blue (Control Input), Gray (Momentary Switch Input)

## **Key Features:**

- Convenient mode switch selects either manual ON or automatic ON operation
- LED status indicator
- Switching is performed at, or close to, the zero-cross of the AC waveform in order to improve relay performance
- 1/2 inch threaded nipple and two lock nuts are used to secure to a standard 1/2" knockout
- Low voltage momentary switch input allows for manual control in automatic or manual mode
- Switching Power Supply provides up to 250mA of 24VDC to low voltage controls
- 20 A receptacle load control rated



UL 2043 Plenum Rated


Load

# **TR 100**


#### **Power Pack**



## Wiring




# Two Stage Multi Level 3-Way Switching




Upon occupancy, lights (Load 1) attached to Power Pack (set to Auto ON) will illuminate automatically while lights (Load 2) attached to Power Pack (set to Manual ON) require the occupant to turn the lights on manually by means of a low voltage switch. All lights can be turned off manually by a low voltage switch or automatically by an occupancy sensor(s).

#### Low Voltage 3-Way Wiring



# **Line Voltage 3-Way Wiring**



## **Product Overview & Mounting**

